



Quick Start Guide
for
sofTV.PresenterLive
On the Pinnacle
Stream Genie







Table of Contents

sofTV.PresenterLive OverView.....	1
<i>sofTV.Presenter.....</i>	<i>1</i>
Configuring a Live Presentation	2
1 <i>sofTV.Presenter.....</i>	2
Creating your presentation.....	2
2 <i>Triggers.....</i>	2
Setting up Triggers for the PowerPoint Slides.....	2
3 <i>Summary</i>	2





sofTV.PresenterLive OverView

sofTV.PresenterLive allows you to create web-based streaming video presentations including PowerPoint slides that change in synchronization with the video content. sofTV.Presenter makes building these presentations easy - just follow a few simple steps, click on Publish, and your presentation is complete!

Use of the sofTV.PresenterLive product suite to create a live presentation consists of three to four components:

sofTV.Presenter

The sofTV.Presenter application is used to create a web page from a Presentation Template, a Powerpoint presentation, and a video source. You can choose to create a Video-On-Demand presentation, or a Live Presentation, simply by specifying the video source as a file on your hard disk, or a live video stream. sofTV.Presenter allows you to insert slide sync commands into a Video-On-Demand file, or insert slide sync commands into a live video stream.



Configuring a Live Presentation

1 *softTV.Presenter*

For live presentations, develop your presentation in softTV.Presenter as you would for per recorded video.

Creating your presentation

On the Stream Genie, select the “softTV.net” tab to access softTV.Presenter. Create a publish your presentation as normal. The one difference is that when you set the video source (step 4) enter the URL of your live stream. This is generally the publish point of the Stream Genie’s live stream.

For additional information with softTV.Presenter, please refer to:

<http://www.softv.net/help/presenter/index.htm>

2 *Triggers*

On the Stream Genie, select the “triggers” tab to access softTV.net Trigger properties. This is used to synchronize the images of slides on a web page to a live presentation.

Setting up Triggers for the PowerPoint Slides

On the “triggers” tab, click the “Make Using PowerPoint PPT File”. Browse to the PPT file you used in your presentation. When you select it, you should see a “PPT” folder appear in your workspace on the left as well as a thumbnail of each slide below on the left.

3 *Summary*

Once everything is set up, as described above, during your live encoding, when you double-click on one of the slide thumbnails (IE: the triggers), that trigger is written into the encoded stream. These triggers are also archived if that option was enabled. Any viewer watching the presentation will receive the trigger and a change of the slide will occur.